

In order to adjust the stop and play tension load the tape machine with a 10.5 inch reel of tape. Reach the middle of the tape. Remove the tape from the pinroller assembly, But put something to cover the light sensor to allow you to go and stop. With the spring gauge. Evaluate the tension.

Do the same for both take up and supply.

Play tension is the same